

OBEX™ Rolls Installation Guidelines

General

OBEX™ Rolls come with an impervious vinyl backing.

Bonding of OBEX™ Rolls to the Subfloor

If installation requires that several rolls are fitted next to each other - make sure that the rolls have all been manufactured from the same dye lot.

A. Preparation work:

1. Check measurements
2. Ensure subfloor is level, sound and free of contaminants such as grease. If greasy, clean with degreaser and prime if necessary.
3. Apply adhesive and allow drying. See recommended adhesives on the below chart:

Manufacture	UZIN	BOSTIK	MAPEI	F.Ball
Release bond (Glue stays soft when dry - allowing easy product release)	Universal tackifier	-	Ultrabond Eco 810	F41
Permanent bond (Glue becomes hard when dry - making product release difficult)	KR430 KE2000S	PowerElastic GreenFusion 2	Ultrabond G 21 Ultrabond Eco 560 Ultrabond G 19	F45 F61
Vertical bond (For use on vertical surfaces such as steps or stariway)	WK222	PowerElastic GreenFusion 2	Ultrabond G 21 Ultrabond Eco 560 Ultrabond G 19	F61

For optimum stability through the lifetime of the installation it is recommended to use a permanent adhesive. When fitting product on stairs, and when installing rolls side by side, a permanent adhesive must be used for seams to secure durable bond on these specific areas.

4. Lay material ensuring that pile direction is consistent throughout and that any joins are overlapped, and the patterns aligns.
5. Cut off all excess material using a sharp knife and straight edge.
6. Use roller over the textile to ensure good bonding.

If there is any evidence of pile crushing in transit or storage, renovate pile using a vacuum cleaner with rotary brush.